

## Rubicon Steel Factory Bumpers

If you are using LED Fog Lights that were removed from a factory metal bumper, then you will need to purchase Hyline Offroad part number 600.100.170. This bracket set will allow you to mount this type of LED Fog Light into your new Hyline Bumper or Air Dam Skid Plate.

### Trim the Plastic Light Housing As Shown

